



**CREDIT SALE**



<b>INSERT CHECK OR SWIPE CARD OPTIONS</b> Check Credit Other	Swipe card. Or, press [CREDIT] and then [SALE].
<b>ENTER ACCT #</b>	Swipe card or key in account number and press [ENTER].
<b>EXPIRE DATE MMY</b>	Key in the expiration date in MMY format (example: 1205) and press [ENTER].
<b>LAST 4 DIGITS?</b>	Key in last 4 digits of card and press [ENTER].
<b>SALE AMOUNT? \$0.00</b>	Key in sale amount and press [ENTER].
<b>TIP AMOUNT? \$0.00</b>	Key in tip amount and press [ENTER].
<b>SERVER ID</b>	Key in server number. Press [ENTER].
<b>DIALING APPROVED XXXXX</b> <b>PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT CUSTOMER RECEIPT</b> YES NO	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>APPROVED XXXXX</b>	Press [CLEAR] to return to idle prompt.

**DEBIT SALE**

<b>INSERT CHECK OR SWIPE CARD OPTIONS</b> Check Credit Other	Press [OTHER], [DEBIT], and then press [DEBIT SALE].
<b>SWIPE DEBIT CARD</b>	Swipe card.
<b>PURCHASE AMOUNT? \$0.00</b>	Key in sale amount and press [ENTER].
<b>CASHBACK AMOUNT? \$0.00</b>	Key in cash-back amount and press [ENTER].
<b>TIP AMOUNT? \$0.00</b>	Key in tip amount and press [ENTER].
<b>SERVER ID</b>	Key in server number and press [ENTER].
<b>WAITING FOR PIN ENTRY</b>	Customer enters PIN on PIN Pad. Press [ENTER].
<b>DIALING APPROVED</b> <b>PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT CUSTOMER RECEIPT</b> YES NO	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>APPROVED</b>	Press [CLEAR] to return to idle prompt.

**TIP ADJUSTMENT**

<b>INSERT CHECK OR SWIPE CARD OPTIONS</b> Check Credit Other	Press [EDIT] on the keypad, and then press [CREDIT].
<b>CREDIT TRAN 000</b> Total Amt \$0.00 Tip Amt \$0.00 Auth Code XXXXX Server ID 00000000 < EDIT >	Use arrow buttons to scroll to the appropriate transaction. Press [EDIT].
<b>EDIT TRANS</b> ChgAmt Void TipAmt	Press [TipAmt].
<b>TIP AMOUNT? \$0.00</b>	Key in tip amount and press [ENTER].
<b>CORRECTION OK</b>	Press [CLEAR] to return to idle prompt.



**AUTHORIZATION ONLY**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT], [MORE], and then press [AUTH].
<b>OPTIONS</b>	
Check Credit Other	
<b>ENTER ACCT #</b>	Swipe card or key in account number and press [ENTER].
<b>EXPIRE DATE MMY</b>	Key in the expiration date in MMY format (example: 1205) and press [ENTER].
<b>LAST 4 DIGITS?</b>	Key in last 4 digits of card and press [ENTER].
<b>PREAUTH AMOUNT? \$0.00</b>	Key in pre-auth amount and press [ENTER].
<b>SERVER ID</b>	Key in server number. Press [ENTER].
<b>DIALING APPROVED XXXXXX PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT CUSTOMER RECEIPT YES NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>APPROVED XXXXXX</b>	Press [CLEAR] to return to idle prompt.

**REPRINT**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT], [MORE], [MORE], and then press [REPRINT].
<b>OPTIONS</b>	
Check Credit Other	
<b>ENTER TRANS #</b>	Key in the transaction number, or press [ENTER] to print last.
<b>PRINT CUSTOMER RECEIPT YES NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.

**FORCE SALE**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT], and then press [FORCE].
<b>OPTIONS</b>	
Check Credit Other	
<b>ENTER ACCT #</b>	Swipe card or key in account number and press [ENTER].
<b>EXPIRE DATE MMY</b>	Key in the expiration date in MMY format (example: 1205) and press [ENTER].
<b>LAST 4 DIGITS?</b>	Key in last 4 digits of card and press [ENTER].
<b>FORCE SALE AMOUNT? \$0.00</b>	Key in sale amount and press [ENTER].
<b>TIP AMOUNT? \$0.00</b>	Key in tip amount and press [ENTER].
<b>ENTER AUTH CODE</b>	Press [ENTER].
<b>TRANS DATE MMDYY</b>	Press [ENTER] to default to current date, or key in.
<b>SERVER ID</b>	Key in server number. Press [ENTER].
<b>FORCE SALE OK PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT CUSTOMER RECEIPT YES NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>FORCE SALE OK</b>	Press [CLEAR] to return to idle prompt.

**CREDIT REFUND**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT] and then press [REFUND].
<b>OPTIONS</b>	
Check Credit Other	
<b>ENTER ACCT #</b>	Swipe card or key in account number and press [ENTER].
<b>EXPIRE DATE MMY</b>	Key in the expiration date in MMY format (example: 1205) and press [ENTER].
<b>LAST 4 DIGITS?</b>	Key in last 4 digits of card and press [ENTER].
<b>REFUND AMOUNT? \$0.00</b>	Key in amount of refund and press [ENTER].
<b>SERVER ID</b>	Key in server number and press [ENTER].
<b>REFUND OK PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT COPY CUSTOMER RECEIPT YES NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>REFUND OK</b>	Press [CLEAR] to return to idle prompt.

**DEBIT REFUND**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [OTHER], [DEBIT], and then press [DEBIT REFUND].
<b>OPTIONS</b>	
Check Credit Other	
<b>DEBIT REFUND SWIPE DEBIT CARD</b>	Swipe card.
<b>DEBIT REFUND AMT \$0.00</b>	Key in amount of refund and press [ENTER].
<b>SERVER ID</b>	Key in server number and press [ENTER].
<b>WAITING FOR PIN ENTRY</b>	Customer keys in PIN on PIN Pad.
<b>DIALING APPROVED XXXXXX PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT CUSTOMER RECEIPT YES NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>APPROVED XXXXXX</b>	Press [CLEAR] to return to idle prompt.

**VOID**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [EDIT] on the keypad, and then press [CREDIT].
<b>OPTIONS</b>	
Check Credit Other	
<b>CREDIT TRAN 000</b>	Use arrow buttons to scroll to the appropriate transaction. Press [EDIT].
<b>Total Amt \$0.00</b>	
<b>Tip Amt \$0.00</b>	
<b>Auth Code XXXXXX</b>	
<b>SERVER ID 00000000</b>	
<b>&lt; EDIT &gt;</b>	
<b>EDIT TRANS</b>	Press [VOID].
<b>ChgAmt Void TipAmt</b>	
<b>ENTER PASSWORD</b>	Key in password and press [ENTER].
<b>VOID OK</b>	Press [CLEAR] to return to idle prompt.

**TOTALS REVIEW**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT], [MORE], [MORE], and then press [VIEW REPORT].
<b>OPTIONS</b>	
Check Credit Other	
<b>VIEW</b>	Select the data type you want to view and press the corresponding key.
<b>NET CARD CARD TOTAL TOTAL DETAIL</b>	
<b>SERVER SERVER TABS TOTAL DETAIL</b>	

**TOTAL REPORT**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT], [MORE], [MORE], and then press [PRINT REPORT].
<b>OPTIONS</b>	
Check Credit Other	
<b>PRINT</b>	Select the report type you want to print and press the corresponding key.
<b>NET CARD CARD TOTAL TOTAL DETAIL</b>	
<b>SERVER SERVER TABS TOTAL DETAIL</b>	

**SETTLEMENT**

<b>INSERT CHECK OR SWIPE CARD</b>	Press [CREDIT], [MORE], and then press [CLOSE].
<b>OPTIONS</b>	
Check Credit Other	
<b>CONFIRM CLOSE YES NO</b>	Press [YES].
<b>DIALING CLOSE COMPLETE OK xxx xxxx xxxx</b>	Response displays. Batch prints. Press [CLEAR] to return to idle prompt.

Shaded sections are optional features.

Shaded sections are optional features.

OPEN TAB	
<b>INSERT CHECK OR SWIPE CARD</b>	Swipe card or press [CREDIT], [MORE], and then [TAB].
<b>OPTIONS</b> Check Credit Other	
<b>TABS</b> OPEN      CLOSE	Press [OPEN].
<b>ENTER ACCT #</b>	Swipe card or key in account number and press [ENTER].
<b>EXPIRE DATE MMYY</b>	Key in the expiration date in MMYY format (example: 1205) and press [ENTER].
<b>LAST 4 DIGITS?</b>	Key in last 4 digits of card and press [ENTER].
<b>PRESAUTH AMOUNT? \$0.00</b>	Key in pre-auth amount and press [ENTER].
<b>DIALING APPROVED XXXXXX PRINTING RECEIPT</b>	Response displays. Receipt prints.
<b>PRINT CUSTOMER RECEIPT YES      NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>APPROVED XXXXXX</b>	Press [CLEAR] to return to idle prompt.

CLOSE TAB	
<b>INSERT CHECK OR SWIPE CARD</b>	Swipe card or press [CREDIT], [MORE], and then [TAB].
<b>OPTIONS</b> Check Credit Other	
<b>TABS</b> OPEN      CLOSE	Press [CLOSE].
<b>ENTER TRANS #</b>	Press [ENTER] for all trans. Or, key in a specific Trans #, and press [ENTER].
<b>SALE AMOUNT? \$0.00</b>	Key in the sale amount, and press [ENTER].
<b>TIP AMOUNT? \$0.00</b>	Key in tip amount and press [ENTER].
<b>SERVER ID</b>	Key in server number. Press [ENTER].
<b>TAB CLOSED PRINTING RECEIPT</b>	Receipt prints.
<b>PRINT CUSTOMER RECEIPT YES      NO</b>	Tear off merchant receipt. Press [YES] to print customer copy of receipt.
<b>TAB CLOSED</b>	Press [CLEAR] to return to idle prompt.

POS-0421



02/02 TeleCheck Eclipse Restaurant

Shaded sections are optional features.